




## Loading your Fillable Bag

Lay your Nook on it's back and slide off the door.

Pull off the spout open it up to get some air inside... place the empty fillable bag standing up in the Nook.

While holding the opening of the bag with one hand, pour your own wine or beverage of choice into the bag.



Once full (a bag can hold four 750 milliliter bottles of wine), put the spout back on and click until all the way closed.

Place into the Nook as you normally would and voila! Enjoy!